

# Walmart

## Loading Scratch-off Tickets

### Tip Sheet

- Open door
- Code 123456
- Password 1234
- Press - Inventory management button
- Select Bin #
- Press - Unload Tickets button
- Clear inventory question Yes or No                      Choose Yes
- Inventory screen should be clear of game info and inventory
- Now ready to load new game
- Press - Load inventory button
- Take one pack of appropriate ticket
- Scan first ticket #000 - SUBMIT
- Scan Last ticket - SUBMIT
- Physically load ticket - highest number ticket first
- Verify inventory - if any discrepancies start over
- If inventory is correct move onto next game
- Confirm and Print inventory report when finished
- Games should appear on the front touch screen if successful

